


FIG. 1



0989730.070301

FIG. 2




FIG. 3





FIG. 4



0989730-07601

FIG. 5A

Enter the weight of clothes. Return
 Weight of clothes Kg Proceed

| | | |
|---|---|--------|
| 7 | 8 | 9 |
| 4 | 5 | 6 |
| 1 | 2 | 3 |
| 0 | . | Delete |
| | | Back |

FIG. 5B

Enter the weight of clothes. Return
 Weight of clothes 1.2Kg Proceed

| | | |
|---|---|--------|
| 7 | 8 | 9 |
| 4 | 5 | 6 |
| 1 | 2 | 3 |
| 0 | . | Delete |
| | | Back |

FIG. 5C

Get on the step base, and
 your body weight will be
 measured. Return
Proceed

Weight of clothes being subtracted

-1.2kg

FIG. 5D

Your body weight is Return
 Weight of clothes being subtracted Proceed

67.0kg

Proceed to the next step, and fill in a
 presented form.

FIG. 5E

Enter your build and sex. Return
Proceed

| | |
|--------------------------------|----------------------------------|
| Male with a Standard Build | Female with a Standard Build |
| Male with an Athletic Build | Female with an Athletic Build |

FIG. 5F

Enter your age. Return
 Age years old Proceed

| | | |
|---|---|--------|
| 7 | 8 | 9 |
| 4 | 5 | 6 |
| 1 | 2 | 3 |
| 0 | . | Delete |
| | | Back |

FIG. 6A

Enter your height.

Height cm

FIG. 6B

Confirm the contents of setting and press the Start key

Contents of setting
 (Press the Return key, and you can modify the contents of setting you can modify the contents of setting)

FIG. 7

Press the Print key for printing

100020"0E26860

FIG. 8




FIG. 9

